

CLEAR/DENORMALIZE, RELEARN/NORMALIZE WITHOUT A SCAN TOOL

With the ignition in the run position hold up/down the window switch for at least 30 seconds until the DTC is set for stuck switch. This will clear the memory of the calibration information. Proceed to relearn/normalize.

1. Put a battery charger on vehicle.

NOTE: The convertible top must be completely closed and locked during this procedure.

NOTE: Both doors need to be completely closed when starting this step.

2. Sit in the driver seat and close the door.
3. Move the driver window part way down.
4. Using the Power Top Switch, raise the window to full up position and continue to hold the top switch for additional two seconds.
5. Using the window switch, lower the driver window to the full down position and continue to hold the switch for additional two seconds.
6. Raise the window to the full up position.
7. Verify that the window drops approximately 1/4 inch when the door opens, and raises when door closes. If window does not drop or raise, repeat procedure starting at step 3.

You can disregard the portion about clearing the dtc's they won't hurt anything as they'll store and eventually delete themselves.