

PRODEMAND

YMMS: 1996 Dodge Grand Caravan SE
Engine: 3.0L Eng
VIN:

Jan 21, 2025
License:
Odometer:

Removal

1. Crankshaft position sensor is located on top of transaxle housing, above flywheel, near corner of rear exhaust manifold.
2. Raise and support vehicle. Disconnect electrical connector at crankshaft position sensor. Remove retaining bolt and crankshaft position sensor.

CAUTION: *If crankshaft position sensor is reused, old paper spacer must be removed from crankshaft end of crankshaft position sensor and a NEW paper spacer installed before installing crankshaft position sensor. If using a NEW crankshaft position sensor, ensure paper spacer is installed on crankshaft end of crankshaft position sensor.*